


65672, 65677, 65682, 65687, 65692

PARTS SCHEMATIC



65672, 65677, 65682, 65687, 65692 Parts List


No.	Description	Q'ty
1	Upper High Pressure Hose	1
2	Seal Kit 22	9
3	Lower High Pressure Hose	1
4	Hose Link	2
5	Upper Guard	1
6	Cylinder Lock Plate	1
7	Pin Holder	2
8	Bolt M8×25 (65677, 65682) Bolt M8×35 (65687, 65692)	6
9	Cylinder	1
10	Bolt M10×25	9
11	Washer 10	7
12	Sleeve 2	1
13	Bolt	2
14	Shaft	1
15	Grip	2
16	Sleeve	2
17	Flat Washer 12	2
18	Cylinder Pin	2
19	Right Operating Lever	1
20	Flat Washer 6	6
21	Flange Nut M12	10
22	Right Plate	1
23	Friction Plate	4
24	Control U-Handle	1
25	Left Plate	1
26	Baffle Plate	2
27	Wedge Weldment	1
28	Pin 12×70	1
29	Screw M12×70	6
30	Retaining Hook	1
31	Grip	1
32	Guard Bracket Left	1
33	Locknut M10	9
34	Locknut M12	2
35	Locating Sleeve	1
36	Hoist Guard	1

No.	Description	Q'ty
37	Bolt M10×35	4
38	Nut M14	1
39	Screw M6×10	1
40	Screw	1
41	Pin	2
42	Locating Plate	1
43	Reset Torsion Spring	1
44	Washer 14	1
45	Big Washer 12	1
46	Bolt M16×90	1
47	Nut M16	1
48	Oil Dipstick	1
49	Hose Connector	1
50	Sealing Kit 20	5
51	Valve	1
52	Screw M6×15	2
53	High Pressure Hose 2 D12	1
54	Nipple M20×1.5-M22×1.5	1
55	Bolt M8×65	2
56	Nut M8	8
57	Oil Return Hose	1
58	Hose Clamp	6
59	Pin ϕ 3	2
60	Round Plate	1
61	Valve Connecting Plate	2
62	Limit Plate	1
63	Bolt M12×45	4
64	Big Washer 10	2
65	Nut M10	13
66	Pressing Plate	1
67	Adjusting Sleeve	1
68	Pull Rod	1
69	Nut M4	4
70	Screw M8×25	4
71	Nut M8	4
72	Pin ϕ 6×45	1
73	Switch	1

No.	Description	Q'ty
74	Knob	1
75	Hoist Chain	1
76	Bolt M10×40	1
77	Screw M4×60	4
78	R-Pin	1
79	Pin	1
80	Nut M22×1.5	2
81	Pin ϕ 6X35	1
82	Screwed Plug	1
83	Main Frame	1
84	R-Pin	3
85	Washer 24	4
86	Wheel 10"	2
87	High Pressure Elbow Part	1
88	High Pressure T-Connector	1
89	High Pressure Hose 1	1
90	Nipple Zg 1/2-M22×1.5	2
91	One-Way Valve D=12	2
92	Gear Pump 1	1
93	Flange Plate	1
94	Bolt M8×30	4
95	Gear Pump 1	1
96	Spring	1
97	Elastic Ring Pin Assy	2
98	O-Ring 81×3.1	1
99	Oil Filter	1
100	Wheel Axle	1
101	Screw M6×14	6
102	Suction Hose 1	1
103	Bolt M10×20	2
104	Accelerator	1
105	Screw M8×30	4
106	Coupler 1	1
107	Suction Hose 2	1
108	Low Pressure Elbow Part	1
109	Low Pressure T-Connector	1
110	Set Screw M10×40	2
111	Coupler 2	1
112	Spline Shaft Sheath	1

No.	Description	Q'ty
113	Key 8×50	1
114	Motor	1
115	Coupling Rubber Ring	1
116	Pump Bracket	1
117	Valve Connector	2
118	Flat Washer 22	2
119	Cylindrical Pin 8×70	1
120	Adjusting Bar	1
121	Bolt M8×45	1
122	Flat Washer 8	2
123	Reset Tension Spring	1
124	Washer 8	4
125	Locknut M8	3
126	Bolt M8×20	2
127	Bolt M8×20	2
128	Adjusting Knob M8	2
129	Log Fixing Claw	1
130	Cam Friction Pad	1
131	Locknut M5	2
132	Bolt M5×16	2
133	Extended Log Fixing Claw	1
134	Reset Spring	1
135	Cylindrical Pin 5×35	1
136	Spring Washer 10	2
137	Support Plate	1
138	Bolt M10×20	2
139	Support Wheel	1
140	Pressing Lever	1
141	Support Arm	1
142	Pin 12	1
143	Rotating Shaft	1
144	R-Pin	1
145	Shaft Guard	1
146	Screw 3×25	2
147	Microswitch	1
148	Nut M3	2
149	Spring	1

25210



25210 Parts List

No.	Description	Q'ty
1	Long Bush	1
2	Rope Pressing Plate	1
3	Limit Plate	2
4	Bolt M10×30	1
5	Bolt M10×50	1
6	Washer 10	8
7	Bolt M10×120	3
8	Bolt M8×50	1
9	Bolt M16×85	1
10	Lockbut M8	4
11	Rope Bracket	1
12	Pulley Plate	2
13	Pressing Plate	1
14	Flat Washer 10	2
15	Hydraulic Valve	1
16	Bush	2
17	Pulley	1
18	Support Plate 2	1
19	Roller	1
20	Support Plate 1	1
21	Hydraulic Motor	1
22	Washer 12	2
23	Spring Washer 12	2
24	Bolt M12×30	2
25	Sealing Kit G1/2	4
26	Nipple G1/2-M18×1.5	4
27	Lock Ring	4
28	Lock Nut	4
29	Bolt M8×55	3
30	Hose 2	1

No.	Description	Q'ty
31	Hose 1	1
32	Low Pressure Elbow Part	1
33	Nipple ZG1/2-M22×1.5	1
34	Locknut M16	1
35	Bush	1
36	Bolt M10×45	2
37	Washer 16	2
38	Washer 8	2
39	Locknut 10	7
40	Oil Return Hose	1
41	Hose Hoop	2
42	Oil Inlet Hose	1
43	Hook 1T	1
44	Rope 6×19.5M	1
45	Rope Buckle	1
46	Flat Pipe	1
47	Bolt M16×45	2
48	Washer 16	4
49	Nut M12	2
50	Flat Washer 12	4
51	Nut M16	2
52	Bolt M12×110	2
53	Flange Bolt M8×25	2
54	Support Plate	1
55	Flat Washer 10	2
56	U-Bolt	1
57	Fixing Plate	1
58	Bolt M10	2